

## Using McKAL MP867-IR (InfraRed) for memory cards on Windows 7


This guide will guide you through the setup of the necessary drivers on your **Windows 7** system.

### A What you need


1. **McKAL** MP867-IR Direct AIO Cardreader

### B Setting up your PC/Laptop with the drivers

1. Plug in MP867-IR into your Windows 7 system.
2. Your Windows 7 system will auto-detect the hardware.
3. Step through the instructions to complete installation.
4. After drivers installation is completed, plug in your MP867-IR into your USB port, wait for the system to auto-detect the device.
5. You may see either of these messages




Or




This is the expected response from Windows 7.


6. Next go to
  - a) Start > Control Panel
  - b) System and Security
  - c) Click on "Device Manager" under "System" and the following screen appears




7. Right-click on “eHome Infrared Receiver” and select “Update Driver Software...”




a) Next, select “Browse my computer for driver software”




b) Select “Let me pick from a list of device drivers on my computer”




c) Select “USB Composite Device”



d) Let the system complete the driver installation and the following screen will appear.



8. After installation completed, you will see the Smart card reader and “eHome Infrared Receiver (USBCIR)” listed in the Device Manager. You may get an additional device driver with a warning, that warning can be ignored.



9. This will complete the drivers installation on Windows 7 and you can use MP867-IR to read all card formats except SmartCard or Cashcard.

If you intend to use the MP867-IR cardreader for SmartCard or Singapore Cashcard, please download <http://www.mckal.com/download/MP866-867-901cashcardguidev4.pdf>.

~ END ~

**Disclaimer**

For Java support, please check with your system technical support.  
© MMXI **MCKAL**, All Rights Reserved.